



# Instruction Manual

## Stringing a New Safety Bobber



Attach the line stop by pulling the line through the wire loop and sliding the line stop onto the line. Push the fishing line through the hole on the top of the bobber. Make sure the line stop is positioned on the fishing line above the bobber.



Open the sides of the bobber and pull the string down about six inches. Tie on a weight and hook.



TIP

For fishing tips and instructions on how to attach a weight and hook to your rod please visit our website at [www.rocketfishingrod.com](http://www.rocketfishingrod.com)



### WARNING:

This is not a toy. Not for use by children under 8 years of age. To be used only with adult supervision. Do not aim or launch in the direction of people or pets. Do not insert anything other than the recommended bobber into product. This may cause serious injury.



### CAUTION:

This product contains a functional sharp hook. Adult assembly required for fishing hooks. Take extra care during unpacking and use.

317010-v1-0515

© 2015 Goliath BV, Vijzelpad 80, NL 8051 KR Hattum. ©2015 Goliath Games LLC, 3701 West Plano Parkway, Suite 100, Plano, Texas, 75075, USA. Warning. Keep this information for future reference. Colors and contents may vary from those illustrated. © 2015 The Dennis G. Wyman Living Trust and Meo Mio, LLC. Made Under License from The Dennis G. Wyman Living Trust and Meo Mio, LLC. Manufactured in Shaoguan, GuangDong, China. Do not return to store. For help call 855-258-8214 (toll-free) or visit: [www.goliathgames.us](http://www.goliathgames.us)

# 31701



[www.rocketfishingrod.com](http://www.rocketfishingrod.com) | [www.goliathgames.us](http://www.goliathgames.us) | (855) 258-8214